

FLEX-Elektrowerkzeuge GmbH  
Bahnhofstraße 15  
71711 Steinheim  
Phone +49 7144 828-0  
Fax +49 7144 25899  
info@flex-tools.com  
www.flex-tools.com

**FLEX**  
Das Original

## Cordless circular saw with pendulum hood 18,0 V

### CS 62 18.0-EC/5.0 Set

Order number 454.028



#### Cordless circular saw with pendulum hood 18,0 V

- + Electronic management system (EMS) protects the machine, extends the service life, and increases efficiency
- + Brushless motor with greater efficiency and a longer service life
- + 18.0 V EC motor with overload protection and temperature monitoring
- + LED battery capacity display
- + Dual clamped swivel element prevents the saw blade from jamming when making mitre cuts and therefore the risk of recoil
- + Spindle lock: for quick replacement of blades
- + Angle scale from 0 ° to 50 °. With preset angles of 22.5° / 45°, and 50°. Easy to read, precision adjustment via non-slip clamping elements
- + Swivel range from -1° to 50° for undercuts as well as scoring function for perfect visible edges
- + Intuitive clamp lever for cutting depth adjustment, cutting depth is easy to read off
- + In accordance with the latest regulations without splitting wedge for plunge cuts and without time-consuming removal of splitting wedge
- + Woodshaving collection bag for low-dust operation, simple to empty, tool-free attachment by means of bayonet connection
- + Connector for external dust extraction Ø 27 mm or step adapter
- + Ideal for traditional applications in dry construction and refurbishing, e.g. for making saw cuts through plasterboard, concrete fibre boards, wood materials, such as chipboard or OSB boards

#### Technical attributes

Battery voltage	18 V
Battery capacity	2,5 / 5,0 Ah
No load speed	5000 rpm
Pivoting range	0-50 °
Saw blade holder	20 mm
Cutting depth	0-62 mm
Depth of cut - mitre cut	0-38 mm
Depth of cut - mitre cut with guide rail	0-32 mm
Blade Ø	165 mm
Angle preset	0°/22,5°/45°/50°
Size ( W x L x H )	335 x 190 x 210 mm
Weight without battery	3,1 kg

#### Standard equipment

1 saw blade Z 24-WZ	456.012
1 dust bag	1 piece
1 extraction adapter	1 piece
2 batteries 5.0 Ah AP 18.0/5.0	445.894
1 charger CA 10.8/18.0	417.882
1 carrying case L-BOXX® 374	414.107
1 case insert	459.380